


# MXQ Series

ø6, ø8, ø12, ø16  
ø20, ø25



## Construction



\* The numbers correspond with those in the "Construction" of the MXQ series in the **Web Catalog**.

### Seal Kit List

No.	Description	Material	Note
18	Piston seal	NBR	
19	Rod seal		
20	O-ring		

### With end lock

35	Piston seal	NBR	
36	Rod seal		
37	O-ring		
38	O-ring		

### Axial piping type

44	O-ring	NBR	
45	O-ring	NBR	
46	Gasket	NBR, Stainless steel	
47	O-ring	NBR	

\* The seal kit includes these seals to provide as a set. Order the seal kit based on each bore size.

### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
6	MXQ6-PS	Set of nos. 18, 19, 20
8	MXQ8-PS	
12	MXQ12-PS	
16	MXQ16-PS	
20	MXQ20-PS	
25	MXQ25-PS	

### Replacement Parts: Seal Kit for with End Lock

Bore size (mm)	Part no.	Contents
8	MXQ8R-PS	Set of nos. 18, 19, 20, 35, 36, 37, 38
12	MXQ12R-PS	
16	MXQ16R-PS	
20	MXQ20R-PS	
25	MXQ25R-PS	

### Replacement Parts: Seal Kit for Axial Piping Type

Bore size (mm)	Part no.	Contents
6	MXQ6P-PS	Set of nos. 18, 19, 20, 44, 45, 46, 47
8	MXQ8P-PS	
12	MXQ12P-PS	
16	MXQ16P-PS	
20	MXQ20P-PS	Set of nos. 18, 19, 20, 44, 45, 46
25	MXQ25P-PS	

### Replacement Parts: Grease Pack

Applied section	Grease pack part no.
Guide	GR-S-010 (10 g)
	GR-S-020 (20 g)
Cylinder	GR-L-005 (5 g)
	GR-L-010 (10 g)