
# **Compact Slide**

ø6, ø10, ø16, ø20, ø25

# Improved linear guide rigidity










## **High Rigidity Achieved**

Increased rigidity by extending the guide length of the linear guide. Significantly reduced table displacement when a moment is applied.




CHERA V

STATE 1

## Weight Max. 6% reduction

(1)

194 g  $\rightarrow$  182 g (Compared with the existing MXH series ø16 and 5 mm stroke)



Small auto switches capable (D-M9, D-A9)

OUT port

IN port




### **Dimensions for mounting and** length are equivalent to the existing MXH series.


Dimensions including workpiece mounting dimensions and cylinder mounting dimensions are the same as the existing model.

### Piping is possible in 3 directions.


If changing the port location, "Made to Order" model (-XC3D) is available.



### Mounting is possible in 4 directions.



### 2 mounting options for workpieces are available.



Front	mountin	g
	<u>م</u>	© ©

### Bumper

A bumper is also installed inside the cylinder.

For details, refer to page 11, "Construction."

### Variations

	Action	Cushion	Bore size [mm]	Stroke [mm]	Made to Order (pp. 23 to 25)
MXH2			6	5 to 60	-XB13 : Low-speed cylinder (5 to 50 mm/s)
		Rubber bumper on	10	5 to 100	-XC3 : Special port location
in the	Double acting		16	5 to 125	-XC19 : Intermediate stroke (Spacer type)
1. 30	doung		20	5 to 150	-XC22 : Fluororubber seals
			New 25	5 to 150	-XC79 : Machining tapped hole, drilled hole and pin hole additionally

### CONTENTS

Ν


Model Selec	ction	р. З
How to Ord	er	·р.9
Specificatio	ns	p.10
Constructio	n	p.11
Dimensions		p. 12
Auto Switch	Mounting	p. 21
Simple Spe	cials·····	p. 23
-XC79	Tapped hole, drilled hole, pinned hole machined additionally $\cdot \cdot$	p. 23

Made to Or	lade to Order Common Specifications p. 24								
-XB13	Low-speed cylinder (5 to 50 mm/s) p. 24								
-XC3□	Special port location p. 24								
-XC19	Intermediate stroke (Spacer type) p. 25								
-XC22	Fluororubber seals p. 25								


## **MXH2** Series **Model Selection**

**Caution** Confirmation of theoretical output is required separately. Refer to "Theoretical Output" on page 10.


Selection Conditions: Follow the tables below in order to determine selection conditions and choose one selection graph.





			60 mm s		5	75 to 150 mm stroke				
	ø <b>6</b>	ø <b>10</b>	ø <b>16</b>	ø <b>20</b>	ø <b>25</b>	ø <b>10</b>	ø <b>16</b>	ø <b>20</b>	ø <b>25</b>	
H dimension [mm]	24.5	30.5	34.5	41.5	48.5	32.5	36.5	45.5	53	




### Selection Graph 1 to 3 (Vertical Mounting)







### Selection Example (Vertical Mounting)



Selection conditions Mounting: Vertical Max. speed: 300 mm/s Overhang L: 40 mm Load mass m: 0.2 kg

\* The load mass m should be: mass of workpiece + mass of moving parts (see table below).

Refer to Graph 2 based on vertical mounting and a speed of 300 mm/s. From Graph 2, as the intersection of overhang L: 40 mm and load mass m: 0.2 kg is in the area below the ø10 line, a ø10 is selected.


#### Mass of Moving Parts

[kg


Bore size	Stroke [mm]												
[mm]	5	10	15	20	25	30	40	50	60	75	100	125	150
6	0.02	0.02	0.03	0.03	0.03	0.03	0.03	0.03	0.04	—	-	_	—
10	0.04	0.04	0.05	0.05	0.05	0.05	0.06	0.06	0.06	0.08	0.10	_	—
16	0.08	0.08	0.09	0.09	0.09	0.09	0.10	0.11	0.11	0.14	0.16	0.19	—
20	0.14	0.14	0.15	0.15	0.16	0.16	0.17	0.18	0.19	0.24	0.28	0.31	0.35
25	0.24	0.24	0.26	0.26	0.27	0.27	0.29	0.30	0.32	0.37	0.42	0.47	0.52




### Selection Graph 4 to 12 (Horizontal Mounting)



### Selection Example (Horizontal Mounting)





Refer to Graph 6 based on horizontal mounting, a speed of 100 mm/s and load eccentricity L1 of 200 mm. From Graph 6, as the intersection of overhang L: 30 mm and load mass m: 1.0 kg is in the area below the ø16 line, a ø16 is selected.

### Mass of Moving Parts


Mass of	Mass of Moving Parts [kg]													
Bore siz	ze						Sti	roke [m	וm]					
[mm]		5	10	15	20	25	30	40	50	60	75	100	125	150
6		0.02	0.02	0.03	0.03	0.03	0.03	0.03	0.03	0.04	-	-	_	—
10		0.04	0.04	0.05	0.05	0.05	0.05	0.06	0.06	0.06	0.08	0.10	_	—
16		0.08	0.08	0.09	0.09	0.09	0.09	0.10	0.11	0.11	0.14	0.16	0.19	—
20		0.14	0.14	0.15	0.15	0.16	0.16	0.17	0.18	0.19	0.24	0.28	0.31	0.35
25		0.24	0.24	0.26	0.26	0.27	0.27	0.29	0.30	0.32	0.37	0.42	0.47	0.52




### Table Displacement (Reference)


#### Table displacement due to a force acting in the pitch direction

The amount of Table end displacement when load F is applied directly at the end of stroke in the pitch direction.





L and α by Bore Size and Stroke [mm]										
Stroke	Ø	6	ø	ø <b>10</b>		ø <b>16</b>		20	ø <b>25</b>	
Stroke	L	α	L	α	L	α	L	α	Г	α
5, 10	30		35		39		46		58	
15, 20	40		45	16	49	19	56	19	68	26
25, 30	50	14	55		59		66		78	
40	60	14	65		69		76		88	
50	70		75		79		86		98	
60	80		85		89		96		108	
75			101	- 1	107		111		122	
100	]			14	132	16	136	20	147	27
125	/				157		161	20	172	21
150	$\vee$			-		$\sim$	186		197	



The displacement values are taken from a downwards pushing force acting directly on the end of the table. This includes any displacement due to the elastic deformation of the guide rolling assembly. \* **SMC** 

### Model Selection MXH2 Series


#### Table displacement due to a force acting in the yaw direction

The amount of Table end displacement when load  ${\sf F}$  is applied directly at the end of stroke in the yaw direction.


L1: Load eccentricity

E.

Calculate the table end load F using the following formula. (Refer to the table below for L and  $\alpha$  values.)



L and $\alpha$ by	L and $\alpha$ by Bore Size and Stroke [mm]									
Chucke	Ø	6	Ø	ø <b>10</b>		ø <b>16</b>		20	ø <b>25</b>	
Stroke	L	α	L	α	L	α	L	α	L	α
5, 10	30		35		39		46		58	
15, 20	40	1	45		49		56		68	
25, 30	50	14	55	16	59	19	66	19	78	26
40	60	14	65		69		76		88	
50	70		75		79		86		98	
60	80		85		89		96		108	
75			101	- 4	107		111		122	
100				14	132	16	136	20	147	07
125							161	20	172	27
150				-	-	$\sim$	186		197	




### **Table Displacement (Reference)**


#### Table Displacement due to a moment force acting

#### in the roll direction

7

The amount of table displacement (at arrow A) with respect to the roll moment Mr when load F is applied to arrow F at the cylinder's stroke end





### **Traveling Parallelism for a Table**

	Stroke [mm]									
Traveling	5 to 30	40 to 60	75	100	125	150				
parallelism	0.05 mm or less	0.1 mm or less	0.13 mm or less	0.17 mm or less	0.21 mm or less	0.25 mm or less				

\* A table deflection caused by load fluctuation, etc. is not included.

### Allowable Moment

			[N·m]
Bore size	Pitch moment	Yaw moment	Roll moment
[mm]	Мр	My	Mr
MXH6	0.81	0.81	1.40
MXH10	1.69	1.69	3.19
MXH16	3.49	3.49	6.47
MXH20	5.86	5.86	11.66
MXH25	8.20	8.20	12.72


#### Design

### **≜**Caution

1. Selection of a bore size cannot be made only with above allowable moment.

Select a bore size in accordance with "Model Selection" on pages 3 and 4.


2. If the output of the compact slide is applied directly to the table, make sure it is applied along the rod axial line.



#### **Backlash in the Stroke Direction**


### **Caution**

1. Since the connection between the piston rod and table is a floating mechanism, the table has backlash in the stroke direction.



Connecting part of piston rod and table

## **Compact Slide MXH2** Series ø6, ø10, ø16, ø20, ø25



Refer to "Standard Strokes" on page 10.

#### Applicable Auto Switches / Refer to the Web Catalog for further information on auto switches.

		Fleetwisel	tor		L	oad vo	ltage	Auto swit	ch model	Lead	wire l	engtl	h (m)	Pre-wired												
Type Special function	Electrical entry	Indicator	Wiring (Output)	D	С	AC	Perpendicular	In-line	0.5 (Nil)		0	5 (Z)	connector	Applicab	le load											
۔ ج				3-wire (NPN)		5 V,		M9NV	M9N			۲	0	0	IC circuit											
switch	_			3-wire (PNP)		12 V		M9PV	M9P			۲	0	0												
S				2-wire		12 V		M9BV	M9B			۲	0	0	_											
auto	Discussion in discription	Discussion indication	dicator) Grommet Y	(2-color indicator)		3-wire (NPN)		5 V,		M9NWV	M9NW			۲	0	0		Delevi								
	0	br) Grommet Yes t			Grommet	Grommet	Grommet	Grommet	Grommet	Grommet	Yes	3-wire (PNP)	24 V 12 V	12 V	_	M9PWV	M9PW			۲	0	0	IC circuit	Relay, PLC		
state														2-wire		12 V		M9BWV	M9BW			٠	0	0	- 1	
lst	Mater resistant											3-wire (NPN)	1	5 V,		M9NAV*1	<b>M9NA</b> *1	0	0	۲	0	0	IC circuit			
Solid	Water resistant (2-color indicator)			3-wire (PNP)		12 V	V	M9PAV*1	<b>M9PA</b> *1	0	0	٠	0	0												
Ň				2-wire		12 V		M9BAV*1	<b>M9BA</b> *1	0	0	۲	0	0	—											
Reed auto switch		Yes	Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	-	_	IC circuit	_										
to s	_	Grommet		2 wiro	24.1/	10.1/	100 V	A93V*2	A93			۲		—	—	Relay,										
aut							No	2-wire	24 V	12 V	100 V or less	A90V	A90		-		-	_	IC circuit	PLC						

\*1 Water-resistant type auto switches can be mounted on the above models, but SMC cannot guarantee water resistance.

\*2 The 1 m lead wire is only applicable to the D-A93.

- \* Lead wire length symbols: 0.5 m..... Nil
  - 1 m ..... M 3 m .....L

\* For details on auto switches with pre-wired connectors, refer to the Web Catalog. \* Auto switches are shipped together with the product but do not come assembled.

- 5 m ..... Z
- \* Refer to page 22 for applicable auto switches other than listed above.

- (Example) M9NWZ

\* Solid state auto switches marked with a "O" are produced upon receipt of order.

RoHS

#### 9




(Example) M9NW (Example) M9NWM (Example) M9NWL

### Compact Slide MXH2 Series



#### Symbol Rubber bumper



Made to	Made to Order
Order	(For details, refer to pages 23 to 25.)
	(i or details, refer to pages 23 to 25.)

Symbol	Specifications
-XC79	Tapped hole, drilled hole, pinned hole machined additionally
-XB13	Low-speed cylinder (5 to 50 mm/s)
-XC3	Special port location
-XC19	Intermediate stroke (Spacer type)
-XC22	Fluororubber seals

### **Specifications**

Bore si	6	10	16	20	25				
Fluid				Air					
Action				Double acting	3				
Piping port size				M5 x 0.8					
Minimum operati	0.2 MPa	0.1	MPa	0.08 MPa	0.06 MPa				
Maximum operat	ing pressure			0.7 MPa					
Proof pressure		1.05 MPa							
Ambient and fluid	d temperature	Without auto switch: -10 to 70°C (No freezing) With auto switch: -10 to 60°C (No freezing)							
Piston speed		50 to 500 mm/s							
Allowable kinetic	energy [J]	0.0125	0.025	0.05	0.1	0.175			
Lubrication	Non-lube								
Lubrication Guide unit		Lubrication recommended*1							
Cushion	Rubber bumper on both ends								
Stroke length tol	+1.0								

\*1 Depending on the operating conditions and environment, the performance of the linear guide can be significantly prolonged by regularly greasing the linear guide rails. A grease pack is not included. Order it separately. Grease pack part no.: GR-S-010 (10 g)

### **Standard Strokes**

Bore size [mm]	Standard stroke [mm]
6	5, 10, 15, 20, 25, 30, 40, 50, 60
10	5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 100
16	5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 100, 125
20	5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 100, 125, 150
25	5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 100, 125, 150

\* Intermediate strokes are available with "Made to Order" model (-XC19). (For details, refer to page 25.)

### **Theoretical Output**

						[N]
Bore size	Rod size	Operating	Piston area	Opera	ting pressure	[MPa]
[mm]	[mm]	direction	[mm <sup>2</sup> ]	0.3	0.5	0.7
6	3	OUT	28	8	14	19
0	3	IN	21	6	10	14
10	4	OUT	78	23	39	55
10		IN	66	19	33	46
16	6	OUT	201	60	101	141
10	0	IN	172	51	86	121
20	8	OUT	314	94	157	220
20	0	IN	264	79	132	185
25	10	OUT	491	147	245	344
20	10	IN	412	124	206	289

### Weight

													[g]
Bore size						Str	oke [m	im]					
[mm]	5 st	10 st	15 st	20 st	25 st	30 st	40 st	50 st	60 st	75 st	100 st	125 st	150 st
6	61	68	75	82	89	96	110	124	137	—	-	—	—
10	103	113	124	134	144	154	174	195	215	259	312	—	—
16	182	196	210	224	238	251	279	306	333	406	481	554	—
20	347	370	392	415	438	460	505	550	596	706	826	948	1069
25	470	473	521	524	572	575	624	675	726	834	968	1102	1237


#### Refer to pages 21 and 22 for cylinders with auto switches.

- · Minimum Stroke for Auto Switch Mounting
- · Auto Switch Proper Mounting Position (Detection at Stroke End) and Mounting Height
- · Operating Range
- · Auto Switch Mounting




### Construction

ø6 to ø16



ø**20,** ø**25** 




#### **Component Parts**

No.	Description
1	Cylinder tube
2	Guide
3	Table
4	Piston
5	Magnet
6	Bumper
7	Bumper
8	Piston seal
9	Gasket

### Dimensions: $\emptyset 6$


### 5 to 60 mm stroke



					[mm]
Stroke	J	LA	LB	LT	NS
5	4	10	_	42	14
10	4	10	_	47	14
15	4	20	—	52	24
20	4	20	—	57	24
25	4	30	_	62	30
30	4	30	_	67	30
40	6	20	20	77	45
50	6	25	25	87	55
60	6	30	30	97	60

### Dimensions: Ø10


### 5 to 60 mm stroke



					[mm]
Stroke	J	LA	LB	LT	NS
5	4	10	_	49	14
10	4	10	_	54	14
15	4	20	_	59	24
20	4	20	_	64	24
25	4	30	-	69	30
30	4	30	_	74	30
40	6	20	20	84	45
50	6	25	25	94	55
60	6	30	30	104	60

### Dimensions: Ø10


### 75 and 100 mm stroke




		[mm]
Stroke	LT	NS
75	119	75
100	144	100

### Dimensions: Ø16

### 5 to 60 mm stroke







					[mm]
Stroke	J	LA	LB	LT	NS
5	4	10	_	58	20
10	4	10	—	63	20
15	4	20	—	68	30
20	4	20	_	73	30
25	4	30	_	78	40
30	4	30	_	83	40
40	6	20	20	93	50
50	6	25	25	103	60
60	6	30	30	113	60

### Compact Slide MXH2 Series

### Dimensions: $\emptyset 16$

#### 75, 100 and 125 mm stroke








						[mm]
Stroke	J	LA	LB	LC	LT	NS
75	6	30	30	_	128.5	75
100	6	30	30	_	153.5	100
125	8	35	35	35	178.5	135

### Dimensions: Ø20

### 5 to 60 mm stroke









					[mm]
Stroke	J	LA	LB	LT	NS
5	4	10	_	69	20
10	4	10	—	74	20
15	4	20	_	79	25
20	4	20	_	84	25
25	4	30	_	89	40
30	4	30	_	94	40
40	6	20	20	104	50
50	6	25	25	114	70
60	6	30	30	124	70

### Dimensions: Ø20

#### 75, 100, 125 and 150 mm stroke







						[mm]
Stroke	J	LA	LB	LC	LT	NS
75	6	30	30	—	136.5	90
100	6	30	30	—	161.5	115
125	8	35	35	35	186.5	140
150	8	35	35	35	211.5	165

### Dimensions: Ø25

### 5 to 60 mm stroke








								[mm]
Stroke	L1	L2	L3	J	LA	LB	LT	NS
5, 10	87	68	30	4	10	—	83.5	35
15, 20	97	78	40	4	20	—	93.5	45
25, 30	107	88	50	4	30	—	103.5	55
40	117	98	60	6	20	20	113.5	65
50	127	108	70	6	25	25	123.5	75
60	137	118	80	6	30	30	133.5	85

### Dimensions: Ø25

#### 75, 100, 125 and 150 mm stroke








						[mm]
Stroke	J	LA	LB	LC	LT	NS
75	6	30	30	_	149	100
100	6	30	30	_	174	125
125	8	35	35	35	199	150
150	8	35	35	35	224	175

## **MXH2** Series **Auto Switch Mounting**

### Minimum Stroke for Auto Switch Mounting

			[mm]		
Ni wala awaɗ	Applicable auto switch model				
Number of auto switches mounted	D-M9□, M9□V	D-M9□W, M9□WV D-M9□A, M9□AV	D-A9□, A9□V		
1 pc.	5	5	5		
2 pcs.	5	10	10		

### Auto Switch Proper Mounting Position (Detection at Stroke End) and Mounting Height



[]: Value of the the D-M9 V, D-M9 WV, and D-M9 AV (): Value of the D-A9□V

								[mm]
Bore size [mm]	[mm] D-M9_A D-M9_A D-M9_AV					49⊡ 9⊡V		
	Α	В	С	W	Α	В	С	W
6	12.0	18.5	6.5	5.5	8.0	22.5	2.5	2.0
<b>10</b> * <sup>1</sup>	10.0	24.5 (26.5)	12.5 (14.5)	_	6.0	28.5 (30.5)	8.5 (10.5)	_
<b>16</b> * <sup>1</sup>	12.0	29.0 (33.5)	17.0 (21.5)	_	8.0	33.0 (37.5)	13.0 (17.5)	_
20	17.5	36.0	24.0	—	13.5	40.0	20.0	—
<b>25</b> * <sup>2</sup>	18.0	39.5 (44.5)	27.5 (32.5)	_	14.0	43.5 (48.5)	23.5 (28.5)	_

\*1 Values in brackets () in the tables are dimensions for 75 mm or longer strokes.

\*2 The values in brackets for size Ø25 are the dimensions for 5, 15, and 25 mm strokes. \* The "W" values in the table indicate the max. auto switch protrusion from the cylinder end surface. Adjust the auto switch after confirming the operating conditions in the actual setting.

\* In the case of models with 5 and 10 strokes, the auto switch may not turn off due to operating range or two auto switches may turn on simultaneously. Fix auto switches outside 1 to 4 mm further than the values in the table above. (If one auto switch is used, make sure that it turns ON and OFF properly; If two auto switches are used, make sure that both auto switches turn ON.)

### **Operating Range**

					[mm]			
Auto switch model	Bore size							
Auto switch model	6	10	16	20	25			
D-M9□, M9□V D-M9□W, M9□WV D-M9□A, M9□AV	3	3.5	5	6	6			
D-A9□, A9□V	5	6	9	11	10.5			


 Values which include hysteresis are for guideline purposes only, they are not a guarantee (assuming approx. ±30% dispersion) and may change substantially depending on the ambient environment.

### 🕂 Auto Switch Mounting

#### When installing in close proximity to each other

When the compact slide with the D-A9 or D-M9 auto switch is used, the auto switches could activate unintentionally if the space between the products is less than the dimension shown in Table 1. Therefore, make sure to provide at least this much clearance. Due to unavoidable circumstances, if they must be used with less distance than the dimensions given in the table on the right, the cylinders must be shielded. Therefore, affix a steel plate or a magnetic shielding plate (MU-S025) to the area on the cylinder that corresponds to the adjacent auto switch. The auto switch could activate unintentionally if a shielding plate is not used.

Table 1.		[mm]	
Bore size [mm]	d	L	
6	5	21	
10	5	25	$\odot$
16	10	35	1
20	15	47	
25	15	47	Ð




Dimensions of a shielding plate (MU-S025) that is sold separately are indicated as reference.

	9
36	

Material: Ferrite stainless steel, Thickness: 0.3 mm Since the back side is treated with adhesive, it is possible to attach to the cylinder.

### Side ported type

When using the side ported type, it is not possible to mount perpendicular type D-A9 $\Box$ V or M9 $\Box$ V auto switches on the side to which the piping is connected.



Other than the applicable auto switches listed in "How to Order", the following auto switches can be mounted. \* Normally closed (NC = b contact) solid state auto switches (D-M9□E(V)) are also available. Refer to the **Web Catalog** for details. MXH2 Series Simple Specials

The following changes are dealt with through the Simple Specials System.

Please contact your local sales representative for more details.

### Tapped Hole, Drilled Hole, Pinned Hole Machined Additionally



This simple special is meant for machining additionally tapped hole, drilled hole, and pinned hole, as requested from customer, on parts designed largely for mounting a workpiece, etc. in the combined air cylinders.

But, for each model, since they have the portions which are impossible to machine additionally, refer to the additional machining limitation.


#### Applicable Series and Component Parts Machined Additionally

Applicable series	Component parts applicable for additional machining
MXH2	Table

### **A**Precautions

- We cannot take any responsibility as for the intensity of holes machined additionally and the effects of decreased intensity for the product itself.
- It will not be plated again for the machined part additionally.
- Be sure to fill in "through" for through-hole, and "effective depth" for blind hole.
- When using by machining through-hole additionally, ensure that the tip of the bolt, etc. for mounting workpiece should not stick into the cylinder side. It may result in an unexpected problem.
- Use caution not to interfere the current mounting hole on the standard products with the hole to be machined additionally. But it is possible to drill additionally the larger size of hole at the same position as the current hole.

#### Common Complementary Explanation/Holes which can be additionally machined are the following 3 types.



### Limitation for Machining Additionally/Since the slanted lines denote the restricted range for machining additionally, design the dimensions, referring to below.

MXH2 series		Table r	naterial: Aluminur
LZ LY Dimensional Range	Not Possible t	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	LX
Bore size [mm]	LX	LY	LZ
6	28	11	8
10	31	14	8.5
16	39	19	8.5
20	48	23	10.5

54

28.5

10.5

25

MXH2 Series Made to Order Common Specifications

Please contact SMC for detailed dimensions, specifications, and delivery times.



Symbol

-XB13

Symbol

-XC3

### 1 Low-speed Cylinder (5 to 50 mm/s)

Stick-slip phenomenon can be prevented, and smooth operation can be achieved even at lower driving speeds between 5 to 50 mm/s.

Description	Model	Action	Note
Compact slide	MXH2	Double acting	

### How to Order



- \* Operate without lubrication from a pneumatic system lubricator.
- For the speed adjustment, use speed controllers for controlling at lower speeds. (AS-FM/AS-M series)

#### **Specifications**

Piston speed	5 to 50 mm/s
Dimensions	Same as the standard type
Additional specifications	Same as the standard type

### 2 Special Port Location

Cylinder with a modified port position in comparison to the standard type.

Description	Model	Action	Note
Compact slide	MXH2	Double acting	


#### How to Order



#### Specifications: Same as the standard type

The port location of a standard product is in the axial direction, and it is shipped as plugged on both sides. However, side ported types can be ordered. A shifting of the plugs is not required by the customer.

#### **Relation between Port Location and Plug Location**





Symbol -XC19

Symbol

### **3** Intermediate Stroke (Spacer type)

Dealing with intermediate strokes by installing a spacer with the standard stroke cylinder.

Description	Model	Action	Note
Compact slide	MXH2	Double acting	Available through the use of 5 or 10 mm spacers

### How to Order

Standard model no.	-XC19

Intermediate stroke (Spacer type)

### **Specifications**

Intermediate stroke Product dimensions and mounting dimensions	Refer to Table 1 below.
Specifications other than the above	Same as the standard type

### Table 1. Intermediate Stroke (Spacer type)

Intermediate									Stroke								
stroke	35	45	55	65	70	80	85	90	95	105	110	115	120	130	135	140	145
Product dimensions and mounting dimensions	Same as 40 mm stroke	Same as 50 mm stroke	Same as 60 mm stroke	Sam	ne as n stroke	Sam	ne as 100	0 mm sti	roke	Sam	ne as 12	5 mm st	roke	Sam	ie as 150	) mm sti	roke

 $\cdot$  Dealing with it by installing a 5 mm or 10 mm width spacer with the standard stroke cylinder

 $\cdot$  Intermediate strokes not listed in the table are available as a special order.

4	Fluororubber	Seals
_	1 1001 01 00001	ooulo

Description	Model	Action	Note
Compact slide	MXH2	Double acting	

#### How to Order

Standard model no.



Fluororubber seals

### **Specifications**

Seal material	Fluororubber			
Ambient temperature range	*1 With auto switch : -10°C to 60°C (No freezing) Without auto switch: -10°C to 70°C			
Specifications that are not listed above Product dimensions and mounting dimensions	Same as the standard type			

\*1 The type of chemical and the operating temperature may not allow the use of this product.



These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

н

Danger : Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury. Marning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Caution: Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

### **Warning**

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

#### 4. Our products cannot be used beyond their specifications. Our products are not developed, designed, and manufactured to be used under the following conditions or environments. Use under such conditions or environments is not covered.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogs and operation manuals.
- 3. Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

\*1) ISO 4414: Pneumatic fluid power - General rules and safety requirements for systems and their components ISO 4413: Hydraulic fluid power - General rules and safety requirements for systems and their components IEC 60204-1: Safety of machinery - Electrical equipment of machines - Part 1: General requirements ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots etc.

### Caution

We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries.

#### Use in non-manufacturing industries is not covered.

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act. The new Measurement Act prohibits use of any unit other than SI units in Japan.

#### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

\*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

#### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

#### **Revision History**

Edition B \* Size ø25 has been added.

\* 3 times better durability has been added.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

### **SMC** Corporation Akihabara UDX 15F,

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 Fax: 03-5298-5362 https://www.smcworld.com © 2024 SMC Corporation All Rights Reserved